

Exploded view diagram of a 12-plate heat exchanger assembly. The components are numbered as follows:

- 1: Top cover plate
- 2: Gasket
- 3: Bolt
- 4: Heat exchanger plate
- 5: Gasket
- 6: Heat exchanger plate
- 7: Bottom cover plate
- 8: Gasket
- 9: Bolt
- 10: Spring
- 11: Gasket
- 12: Bolt



PDF-1412300N